
## 3.aConfiguration of Wireless Infrastructure [Using Access Point].



## **Configuring Command**

At Server0 - configure DHCP Server as -

Select as :Config/Services-> DHCP->start IP Address : 192.168.1.2


Subnet Mask: 255.255.255.0

Now check at each client whether DHCP request is successful or not.

After that Configure Laptop: - for wireless configuration

Switch off the laptop and then remove wired NIC from the laptop and then insert the wireless NIC (Linksys-WPC300N) into laptop and after that switch on the laptop.

**At Access Point** →Assign WEP Key (minimum of 10-digit) at interface.



## At Laptop2

1) configure as shown  $\rightarrow$  Connect laptop to access point.



2) In Desktop select Web browser and check connectivity with DHCP server.

