
# 2. Building and configuring wired topology with two different networks [ using DHCP ].



## **Configuration command**

#### At Router

Click on router and go to CLI Tab.

Router>

Router>enable

Router# config terminal

Router(config)# int fa0/0

Router(config-if)# ip address 192.168.250.254 255.255.255.0

Router(config-if)# no shut

Router(config-if)#exit

Router(config)# int fa0/1

Router(config-if)# ip address 192.168.251.254 255.255.255.0

Router(config-if)# no shut

Router(config-if)# exit

Router(config)#exit


Router#exit

Close the window


### At Server 0

## 1) Select config Tab:


- i) Assign gateway IP address as 192.168.250.254
- ii) Assign DNS Server as 192.168.250.100



2) In Config/Services Tab select DHCP and configure as shown:




3) At server 0 in Desktop Tab select IP configuration and assign static IP address to DHCP Server as shown below




#### At SERVER 1


1) Select config Tab and assign IP address as shown below-



2) In Config/Services Tab select DHCP and configure as shown:



3) At server 1 in Desktop Tab select IP configuration and assign static IP address to DHCP Server as shown below-



To check node connectivity:

1) Ping PC3 from PC1 At PC1 :: ping 192.168.251.254